# ATLAS SYSTEM

# For large suspended low furniture

- > The perfect solution for heavy loads in suspended kitchens and bathroom cabinets.
- > Maximum safety in the vertical loads, anti-tilt, easy machining and regulation.
- > Does not interfere with the smooth running of the top drawers.
- > Easy industrial installation, can be preassembled to ease transport.
- > In combination with the lower support fitting, the furniture can be adjusted in depth, vertically and horizontally.
- > Nominal capacity of 120kgs. per hanger. EN 15939 on B setting (60kg on C setting).













#### ■ Back support fitting and wall plate

# Back support fitting Zinc-plated 625.700.036 50






# Wall plate Zinc-plated 620.860.030 100

















#### Lower support fitting

#### Lower support fitting 32mm.


Zinc-plated	625.800.033	25






Lower support fitting 3mm.

	Zinc-plated	
A - Without flange	628.000.030	
B - Left flange	628.010.036	25
C - Double flange	628.030.034	25
D - Right flange	628.020.035	








Lower support fitting 2 mm.

Zinc-plated	628.110.033	25


With frontal and vertical regulation.





Lower support fitting 0 mm.

Zinc-plated	628.100.034	25








## 2 TECHNICAL DATA

#### ■ Lower supports selection guide


Lower		Adjustments	
support fitting		Frontal (horizontal)	Vertical
32 mm.	Min. 32 mm. Max. 62 mm.	+- 15 mm.	+- 10 mm.
3 mm.	Min. 3 mm. Max. 14,5 mm.	+- 5,5 mm.	+- 6 mm.
2 mm.	Min. 2 mm. Max. 12 mm.	+- 5 mm.	+- 5 mm.
0 mm.		_	+- 5 mm.



#### 2 TECHNICAL DATA












### 3 ASSEMBLY AND ADJUSTMENTS


Example using lower support fitting 32mm.













### 3 ASSEMBLY AND ADJUSTMENTS

Example using lower support fitting 3mm.

